

ESCREO



Preparation

1. Use the tape to frame your ESCREO area.
2. Use the protective cover to avoid dust and paint spills.
3. Smooth the surface with the sanding block.
4. Use the gloves and, if possible, eye protection.



Watch our video tutorials in ESCREO YouTube Channel.

Find the section that applies to you:

ESCREO White/Clear

/Apply the paint no later than 2 hours after mixing the 2 components/

1. Open the tins with the tin opener carefully.
2. Use the stir to mix the 2 components for 5 min.
3. Pour half of the mixture into the tray.
4. Close the rest of the paint in the tin.
5. Apply the 1st layer evenly with paint roller/brush.
6. Wait min. 30 min. and max. 45 min.
7. Apply the 2nd layer and proceed to "Wrap-up!" section.

ESCREO Magnito

/1 extra day for the application process/

1. Stir well the Magnito.
2. Use the extra paint tray/roller to apply the 1st layer.
3. Wait 30 min.
4. Apply the 2nd layer.
5. Wait 45 min.
6. Apply the 3rd layer.
7. Wait 60 min.
8. Apply the 4th layer.
9. Remove the tape.
10. Wait for 12 hrs.
11. Smooth the surface with the sanding block.
12. Proceed to "Primer" section.

Primer

/To change the colour of the surface or after Magnito/

1. Use the extra tray and a paint roller sleeve to apply the 1st layer.
2. Wait between 30 and 60 min.
3. Apply the 2nd layer.
4. Wait between 30 and 60 min.
5. Proceed to "ESCREO White" section.

Wrap up!

/NB! Start writing in 3 days after the paint is dry/

1. Make sure the paint is distributed evenly.
2. Remove the painting tape.
3. Place the "Wet Paint" sign.
4. Let it dry for 3 days before using the wall.
5. Check the other side for maintenance guidelines.
6. Put the "Write on me" sticker on the dry ESCREO wall.